USER'S MANUAL

LL-PFC LOW LOAD – POWER FACTOR CORRECTOR

This document contains the latest technical information about Low Load Power Factor Corrector panel LL-PFC which is a micro-controller based KVAR controller. The product, LL-PFC is sophisticated electronic equipment and, the user is advised to read this User's Manual carefully before attempting to install or operate the equipment.

Trinity Energy Systems Pvt. Ltd.

Published on: 11/07/2019 Document Version: 1.0

-TRINITY------

Warranty statement

Trinity warrants to the original retail purchaser of the Trinity product enclosed with this limited warranty statement that the product, if purchased new and used in the India conforms to the manufacturer's specifications and will be free from defects in workmanship and materials for a period of one year from the date of original purchase, unless expressly stated otherwise by Trinity, in a written format.

Should your Trinity product prove defective during the warranty period, please bring the product securely packaged in its original container or an equivalent, along with proof of the date of original purchase, to our Trinity Dealer or Factory. You are responsible for all costs (shipping, insurance, travel time) in getting the product to the service location. Trinity will, at its option, repair or replace on an exchange basis the defective unit, without charge for parts or labor. When warranty service involves the exchange of the product or of a part, the item replaced becomes Trinity property. The replacement unit may be new or refurbished to the Trinity standard of quality, and at Trinity's option, the replacement may be another model of like kind and quality. Trinity's liability for replacement of the covered product will not exceed the original retail selling price of the covered product. Exchange or replacement products or parts assume the remaining warranty period of the product covered by this limited warranty.

What This Warranty Does Not Cover:

This warranty does not apply to refurbished or reconditioned products. This warranty covers only normal use in India. This warranty does not cover damage to the Trinity product caused by parts or supplies not manufactured, distributed or certified by Trinity. This warranty is not transferable. This warranty does not cover third party parts, components or peripheral devices added to the Trinity product after its shipment from Trinity. Trinity is not responsible for warranty service should the Trinity label or logo or the rating label or serial number be removed or should the product fail to be properly maintained or fail to function properly as a result of misuse, abuse, improper installation, neglect, improper shipping, damage caused by disasters such as fire, flood, and lightning, improper electrical current, interaction with non-Trinity products, or service other than by an Trinity Authorized Service.

The warranty and remedy provided above are exclusive and in lieu of all other express or implied warranties including, but not limited to, the implied warranties of merchantability or fitness for a particular purpose. In the event, the remedies above fail, Trinity's entire liability shall be limited to a refund of the price paid for the Trinity product covered by this limited warranty. Except as provided in this written warranty, neither Trinity Energy Systems Pvt. Ltd. nor its affiliates shall be liable for any loss, inconvenience, or damage, including direct, special, incidental, or consequential damages, resulting from the use or inability to use the Trinity product, whether resulting from breach of warranty or any other legal theory.

TRINITY

Contents

troduction	4		
The Main features Available in this Model	4		
Technical Specifications	5		
stallation and Commissioning	6		
perational Details	7		
Programming Mode	7		
1. Setting Threshold PF	7		
2. Setting Over Voltage Value	8		
3. Setting Time Delay	8		
4. Setting Meter Address	9		
5. Performing Autosense of Capacitor Bank Sizes	9		
Run Mode	10		
1. Run Mode Display Pages	10		
2. Resetting Average PF	11		
3. Freezing and unfreezing the Auto scroll	11		
4. LED Indication	11		
Communication			
RS485 Connection to board	12		
Modbus RTU on RS485 Port12			
Appendix			
DEFINING MULTIPLICATION FACTOR	13		
EXCEPTION CODE	13		

-TRINITY—

Introduction

The LL-PFC Panel is the `intelligence' which controls the automatic system for correction of the power factor. It senses the power factor by taking the ratio of the true-rms KVA of the system, and the KW. The LL-PFC panel calculates the KVAR requirement of the system (VxIxsin ϕ). For correct operation of the panel, however, there are some minimum system requirements to be met. Unless the various points in the system which are mentioned below are correctly setup, proper operation of the panel cannot be expected.

The Main features Available in this Model

- All readings are true RMS measurements
- 16x1 backlit LCD
- Automatic power factor control
- Programmable threshold PF
- Over Voltage Tripping
- Programmable Time Delay from 1 to 5 minutes for step switching
- Meter address selection for RS485 communication



Technical Specifications

Parameters				
-	Type Name			Statistics
		Supply	One Phase and Neutral	
	5	Voltage	Direct Voltage Input Burden	: 160 - 270V L-N : 0.5VA
JANI		Current	Range of Reading Burden	: 0.02 – 45A : < 1.0VA
		Power Supply	Self powered from Mains	
	asic s	Voltage (Volts L-N)	VL-N - Accuracy	: 1.0% of Reading
	ue RMS Ba Parameters	Current	Accuracy	: 1.0% of Reading
	F	Line Frequency	45 to 55 Hz, Accuracy	: 0.5% of Reading For 50Hz
MEASUREMENT	Power	Reactive Power (Q)	Accuracy	: 1.0% of Reading
		Power Factor	Range of Reading Accuracy	: 0.05 - 1.00 Lag/Lead : 1.0% of Reading (I <i>PF</i> I≥0.5)
	ergy	Total Active Energy (KWh)	Range of Reading Accuracy	: 0 to 9999999.9 : 1.0% of Reading
	Ene	Total Apparent Energy (KVAh)	Range of Reading Accuracy	: 0 to 9999999.9 : 1.0% of Reading
SU	Dimen sions	Panel	300 x 230 x 360 mm	
NEO		Display	16 x1 LCD	
-LAI		Operating temp	10°C to 50°C	
SCEL		Weight	8.2 Kgs (Approx.)	
M		Min. Operating Current	20mA	
	Comm.	RS485	Modbus-RTU protocol	

-TRINITY_____

Installation and Commissioning

The unit supports 1P2W type of electrical installation.

Below image shows terminal connections.

	LL - PFC PANEL	
0	TRINITY ENERGY SYSTEMS PVT.LTD 386,Savli G.I.D.C Estate, Manjusar-391775 ,Vadodara, Gujarat, India Tele:+91-9228004452/53/54 , E-mail:info@trinityenergy.co.in web:www.trinityenergy.co.in SR.NO:	
	SYSTEMS: 1P2W VOLTAGE - 240V AC. LOAD - 0 to 40A MAX	

Follow below steps for connections.

- 1. Connect Phase and Neutral for Input to the terminal marked 1 and 2 respectively shown in below images.
- 2. Connect Phase and Neutral of Load to the terminal marked 4 and 3 respectively shown in below images.



TRINITY-

Operational Details

The KVAR based controller LL-PFC Panel is a versatile unit, with all features needed to implement a robust PF maintenance system.

There are basically two modes of operation in LL-PFC Panel

- 1. Programming Mode
- 2. Run Mode.

After supplying power (160 - 270 VAC), the unit will display the power on message, TRINITY ESPL on LCD screen and by default comes into Run mode as shown below.



The unit can now be operated by using the following keys for both the Programming Mode and Run mode:



Programming Mode

To make the LL-PFC Panel suitable for most field conditions and different types of loads, some parameters have been made programmable. The following parameters can be programmed by the user:

- 1. Threshold PF
- 2. Over Voltage tripping value
- 3. Time Delay
- 4. Meter Address
- 5. Auto sense of capacitor Bank

1. Setting Threshold PF

Threshold PF can be set from 0.900 to 0.990. Panel will start control action for PF correction only if System PF goes below Threshold PF in LAG or LEAD. For example if Threshold PF is set 0.980 and system PF is 0.985, Panel will not start control action. If System PF goes below 0.980 then only it will start control action for power factor correction.

To set Threshold PF, proceed as follows.

- 1. In Run Mode, press key for about four seconds continuously. The display will prompt PROG MODE. PRESS[^].
- 2. Press (A) key to enter into programming mode. The display will now prompt:



-TRINITY-----

3. Press key again. Immediately 'P' starts blinking which shows that the parameter can now be changed. Set the Threshold PF value by pressing

A and \bigtriangledown keys according to your desire and then press (\bowtie) key to confirm setting.

4. If other parameters need to be changed, do so using similar method, otherwise press (RUN) key for about four seconds continuously. The panel will restart and enter into Run Mode.

2. Setting Over Voltage Value

Over Voltage value can be set from 250 to 270 volts. If System voltage goes above over voltage value for constant 5 seconds, panel will switch OFF all the capacitor banks and over voltage LED (OV) will be ON. Now if system voltage goes below over voltage value minus 10 volts for constant 5 seconds, it will start control action and switch OFF over voltage (OV) LED.

For example if over voltage value is set 260 volts. If system voltage goes above 260 volts for constant 5 seconds, it will switch OFF all the capacitor banks and switch ON over voltage (OV) LED. Now if system voltage goes below 250 volts (260V-10V=250V), it will start control action and switch OFF over voltage (OV) LED.

To set Over Voltage value, proceed as follows.

- 1. In Run Mode, press key for about four seconds continuously. The display will prompt PROG MODE. PRESS[^].
- 2. Press (A) key to enter into programming mode. Press (A) key again till the prompt shows:

- 3. Press key again. Immediately 'P' starts blinking which shows that the parameter can now be changed. Set the over volt value by pressing and very keys according to your desire and then press key to confirm setting.
- 4. If other parameters need to be changed, do so using similar method, otherwise press key for about four seconds continuously. The panel will restart and enter into Run Mode.

3. Setting Time Delay

Time Delay can be set from 1 to 5 minutes. For the user defined time delay, the panel will not switch ON or OFF any capacitor bank. i.e. Panel will not take control action for PF correction. This is one type of digital dead band.

To set Time Delay, proceed as follows.

TRINITY _____

- 1. In Run Mode, press key for about four seconds continuously. The display will prompt PROG MODE. PRESS[^].
- 2. Press key to enter into programming mode. Press key again till the prompt shows:



- 3. Press key again. Immediately 'P' starts blinking which shows that the parameter can now be changed. Set the Time Delay value by pressing and value by pressing to your desire and then press key to confirm setting.
- 4. If other parameters need to be changed, do so using similar method, otherwise press key for about four seconds continuously. The panel will restart and enter into Run Mode.

4. Setting Meter Address

Meter address can be set from 1 to 255. The unit also supports RS485 communication port and it should therefore be set the Meter Address from 1 to 255 for communication of it.

To set Meter Address, proceed as follows.

- 1. In Run Mode, press key for about four seconds continuously. The display will prompt PROG MODE. PRESS^.
- 2. Press key to enter into programming mode. Press key again till the prompt shows:

- 3. Press key again. Immediately 'P' starts blinking which shows that the parameter can now be changed. Set the Meter Address value by pressing and very keys according to your desire and then press key to confirm setting.
- 4. If other parameters need to be changed, do so using similar method, otherwise press key for about four seconds continuously. The panel will restart and enter into Run Mode.

5. Performing Autosense of Capacitor Bank Sizes

When the Autosense is set to YES, the unit switch ON/OFF all relays one by one. The bank sizes will also display as capacitor banks get sensed one by one and the user therefore must be patient and wait till autosense is in progress. The process is vital for smooth operation of the unit. Once all capacitor banks are sensed, the unit will restart and take control action as per Time Delay.

To get Autosense, proceed as follows.

TRINITY

- 1. In Run Mode, press key for about four seconds continuously. The display will prompt PROG MODE. PRESS^.
- 2. Press key to enter into programming mode. Press key again till the prompt shows:



- 3. Press ^(▶IR) key again. Immediately 'P' starts blinking which shows that the parameter can now be changed. Select the Autosense to YES by pressing ▲ and ▼ keys and then press ^(▶IR) key to confirm setting
- And V keys and then press key to confirm setting.
 The unit starts autosensing the capacitor stages one by one. After completing AUTOSENSEING, the unit will restart and enter into Run Mode.

Run Mode

In the run mode, the various parameters measured by the meter are displayed sequentially on 16x1 backlit LCD.

1. Run Mode Display Pages

Displays	Descriptions
V=230.5 A=10.45	Display shows Voltage and Current.
0.895 LG (0.705)	Display shows system PF with LAG/LEAD indication. Value displayed in bracket is system average PF.
KWh=14.89	Display shows Active Energy.
KVAh=15.76	Display shows Apparent Energy.
NEEDKVAR=2.51	Display shows KVAR value needed to achieve unity PF (1.000).
KVAR=2.51	Display shows System KVAR.

TRINITY _____



2. Resetting Average PF

The integrated average PF parameter shown in display page can be reset by pressing key in Run Mode for about 5 seconds continuously. The integrated average PF is basically the ratio of KWh & KVAh energy consumption. After reset its value will go to 1.000.

3. Freezing and unfreezing the Auto scroll

The Run Mode displays will always auto scroll by default with an interval of about 6 seconds. Each display can be frozen or unfrozen by pressing key and also moved up and down by pressing and $\mathbf{\nabla}$ keys. When display is frozen, it will blink 'F' at the end of 16x1 LCD.

LL - PFC RL1 RL2 RL3 RX/TX @ OV @ RL4 @ RL4 @ Image: Constraint of the second state of the second sta

4. LED Indication

As shown in above image, RL1 to RL4 shows number of capacitors ON/OFF in panel. For example if capacitor 1, 2 and 4 is ON, RL1, RL2 and RL4 LEDs will be ON and RL3 LED will be OFF. Over voltage (OV) LED will be ON if over voltage is detected. RX/TX LED will be ON/OFF while RS485 communication. When panel receives any data GREEN LED will be ON and when panel sends any data, RED LED will be ON.

TRINITY

Communication



RS485 Connection to board

Connect A+ and B- of RS485 to RS232 converter to A+ and B- respectively of connector J17 on board as shown on below image.



The industrial standard RS-485 communication port option is also available in LL-PFC. This option makes it possible for a user to select LL-PFC to provide various system information into a variety of existing or new control systems and communication networks such as EMS/PLC/SCADA.

Modbus RTU on RS485 Port

In order to download live data for the various system parameters, user can use RS485 connecting to SCADA or EMS software. LL-PFC supports an RS485 port with MODBUS-RTU protocol. The station ID for every panel is site selectable. The data which can be read using MODBUS query # 3 (Read Holding Registers) is provided in an address map, with the applicable multiplication factors, vide *Appendix*.

-TRINITY——

Communication line parameters: <u>9600/8/N/1.</u>

The register map is described below. All addresses are in decimal. All parameters are in unsigned long format. If illegal address is sent in the query or the host tries to read more than 40 bytes of data in one query, exception message is generated. The parameters name, address and multiplication factor are mentioned in Appendix.

ADDRESS PARAMETER MF TYPE 200 VOLT x100 Unsigned long 202 Unsigned long MAIN AMPS x100 204 KVAR x100 Unsigned long 206 NEEDKVAR x100 Unsigned long 208 CAP AMPS x100 Unsigned long Unsigned long 210 CAP KVAR x100 KWH x100 Unsigned long 212 214 KVAH x100 Unsigned long ΡF x1000 Unsigned long 216 Unsigned long 218 AVG_PF x1000

Appendix

DEFINING MULTIPLICATION FACTOR

- PF has a multiplication factor of 1000. Thus, a PF value 0.985 LAG will send as 985 for providing resolution. Now if PF value is 0.985 LEAD, it will send 1985. Similarly KWH has a MF of 100. Thus, a KWH value of 148.63 will send as 14863.
- If an attempt is made to read some address other than the valid addresses, the exception response is sent.

EXCEPTION CODE

In the event that the query from the HOST has no communication error, but there is some error in specifying the address of registers to be read, the meter returns an exception message. The format of the exception message will be as under:

	Unit Address	0x83	Exception code	CRC	CRC
--	--------------	------	----------------	-----	-----

Exception Code can have only one value, 02: if the address is not a valid, start address or host has requested more than 40 bytes of data, this code is returned.

-TRINITY—

P.O No.	:
Customer	:
Sr. No.	:
Result of Test	:
Remarks	:
Test engineer	:
Date	:

-TRINITY-